

Jaxxx Hammer 2.0 Instructions

USE

To charge:

Before first use, you will need to charge the Jaxxx Hammer 2.0. There is a small round opening on the bottom of the machine, located directly next to the Suction Cup Mount. Plug in the included 9V charger to this port. The control panel will blink blue while charging, and will stop flashing once fully charged. Average time to fully-charge the Jaxxx Hammer 2.0 is 5-7 hours. To best maintain battery longevity, it is recommended to wait until the battery runs out of power to recharge and to promptly remove it from the charger when the charging is complete.

Using the suction cup:

To attach the suction cup to the Jaxxx Hammer 2.0 you will need to first remove the plastic wing nut from the bolt on the suction cup. Slide the metal bolt out of the bracket. Place the brackets of the suction cup with the mount on the base of the device, taking care to match up the sides with the tick-marks around the hole together, and firmly press together. Once the holes are aligned, you can reinsert the metal bolt and replace the wing nut. Do not tighten the wing nut until the Jaxxx Hammer 2.0 is in the desired angle, then you can tighten the wing nut to lock the device at that angle while in use.

Operation:



- A. Power Button: Press Once to Power on or off
- B. Vibration: Press to cycle through 5 modes, press 3x to stop vibration when on mode 5
- C. Thrusting Mode: Press to cycle through 10 patterns of thrusting
- D. Thrust Power Boost: Press to cycle through 4 thrusting speeds
- E. LED Lights: Press to turn multi-color light display on or off

CARE

Dildo should be cleaned before and after every use. To clean, firmly grasp the dildo and twist slightly counter-clockwise to remove the dildo from the machine. Also unscrew the cover of the dildo area for cleaning. Apply a specially-formulated toy cleaner or liquid anti-bacterial hand soap to the pieces for 1-2 minutes, then rinse clean with warm water and pat or air dry. The exterior base of the machine may be gently wiped with a damp washcloth and small amount of toy-cleaner as needed, taking care not to wet the electrical components. Store the device in a cool, dark location, ideally with dildo not touching other toys.